

Triple Battery Advanced Automatic Charging Relay

Two Independent ACRs in One Device reduce installation space and time. Significantly lowers off-state current draw

Adjustable Auxiliary Battery
Priority provides variable voltage
points for each relay to share
engine battery energy without
sacrificing ability to start

Start/Engine Isolation and Start Assist functions are optional for each relay; allowing protection of sensitive electronics from engine starting events or the option to boost cranking effectiveness.











Eliminates Dead Start Batteries by sharing charge sources with all batteries and isolating batteries when no charge sources are present



Simple & Robust Installation: Integrated sealed plug eliminates corrosion, included DT04 harness. Single device reduces installation time, space, cost and points of potential failure



Additional Low Amp Output can be used to report device status remotely.



Bullet-proof Construction: Sealed unit, high temperature materials allow mounting anywhere. Integrated thermal overload shutdown protection



Ultra Low Off-State Current: Compare two typical ACRs (20 mA) vs Dual ACR @ 1.3 mA



Adjustable Off-Voltage for Auxiliary Battery Priority provides ability to share start battery

energy for auxiliary without risking engine starting ability.



Start/Engine Isolation input option for ensuring sensitive electronics do not experience voltage sags and spikes from the cranking event.



Start Assist input option to ensure maximum cranking amps available when necessary.



4 Year Industry Leading Warranty

Dip Switch Setting Options & Features

24V Model

OFF 2 1 Voltage

OFF Voltage

₽ ₽ 25.5

BB 25

24.7

24.4

B B 25

BB24.7

ΗН 24.4


12.75

12.2

12.5

П 12.35

* DISCONNECT BATTERY FROM POWER DISTRIBUTION SYSTEM BEFORE INSTALLING PRODUCT TO PREVENT ELECTRICAL SHOCK OR PRODUCT DAMAGE



| | | | 12V | Model |
|-------------------------|---|------|-------|----------------|
| ACR #1 Dip | | | 2 1 | OFF Voltage |
| Switch Options | | BB | 12.75 | |
| Ext Input Function 4 | 3 | Lock | 88 | 12.5 |
| Assist | Ш | ON | | 12.35 |
| Start/Eng Isolation | | OFF | HH | 12.2 |
| | | | | |

| ACR #2 Dip Switch Options | | | | |
|------------------------------|---|------------|---|--|
| Ext Input Function 8 | 7 | UV Lock | Ļ | |
| Start Assist | | ON | Ļ | |
| Start/Eng Isolation | B | OFF | ŀ | |
| = Factory Default | | | | |

| DS1-DS2: ACR #1 OFF Voltage Trigger. |
|---|
| Lower settings allow partial battery |
| energy sharing yet ensuring minimum |
| capacity for starting. |
| DS3: Under-voltage Lock-Out Enable, I |

DS3=ON, ACR #1 will NOT close if either terminal < 9.6 Vdc.

DS4: Determines Pin #2 Response Function. DS4=ON, triggers CLOSE if Pin #2 > 8.0 Vdc. DS4=OFF triggers OPEN if Pin #2 > 8.0 Vdc.

DS5-DS6: ACR #2 OFF Voltage Trigger. Lower settings allow partial battery energy sharing yet ensuring minimum capacity for starting.


D\$7: Under-voltage Lock-Out Enable. If DS7=ON, ACR #2 will NOT close if either terminal < 9.6 (19.2) Vdc.

DS8: Determines Pin #3 Response Function. DS8=ON triggers CLOSE if Pin #3 > 8.0 Vdc. DS8=OFF triggers OPEN if Pin #3 > 8.0 Vdc.

4Ⅲ

() = 24V Setting

Dimensions



Methods of Operation

ACRs #1 or #2 turn ON after 30 (or 120) seconds if:

- 1) If UV Lock = OFF: V-sense A or V-sense B/C > 13.1 Vdc, or
- 2) If UV Lock = ON: V-sense A and V-sense B/C > 9.6 Vdc and Vsense A or V-sense B/C > 13.1 Vdc (120 sec), 13.7 Vdc (30 sec)

ACRs #1 or #2 turn OFF after 30 (or 10) seconds if:

1) V-sense B or C < "Off Voltage" (30 sec) per DS1-DS2 or DS5-DS6, or 10 sec if V-sense B or C < "Off Voltage" minus 0.4 Vdc


Start / Engine Isolation Opens ACR #1 or ACR #2 Immediately if:

- 1) If DS4 = OFF and Pin #2 > 8.0 Vdc (for ACR #1), or
- 2) If DS8 = OFF and Pin #3 > 8.0 Vdc, (for ACR #2)
- 3) Isolation can be connected to engine cranking signal or running signal depending on desired duration of isolation

Start Assist Closes ACR #1 or ACR #2 Immediately if:

- 1) If DS4 = ON and Pin #2 > 8.0 Vdc (for ACR #1), or
- 2) If DS8 = ON and Pin #3 > 8.0 Vdc, (for ACR #2)
- 3) Start Assist closes ACR for 30 sec before returning ACR to auto operation, connect to Key Accy signal to ensure close before crank

System Diagram



Status LED Indicator Functions

Bicolor LED



Red Solid / Green Relay Off, Pending Voltage Based On Flash

Red Flash / Green Solid

Relay On, Pending Voltage Based Off Single Red Flash /No Under-Volt Lockout or Start Isolation Engaged

Green Single Green Flash

Start Assist Applied

No LED

Unit OFF/Open, voltage below turn ON

Red Rapid Flash High Current / Temperature OFF/Open

| ecij | | |
|------|--|--|
| | | |
| | | |
| | | |

| Nominal Voltage (Vdc) | 12 | 24 |
|---|---------------------|-----------|
| Input Voltage Range (Vdc) | 8.0-18.0 | 16.0-36.0 |
| Continuous Current (Amps) | 80A / 160A | |
| Max 5 Min Current (Per Circuit/Total) | 120 A / 240A | |
| Operating Current (Per Circuit) | 170 mA | 85 mA |
| Operating Current, Relays Open | 1.3 mA | 1.3 mA |
| Over Voltage Protection (Vdc) (5 sec) | 17.0 | 35.0 |
| Under-Voltage Lockout (Vdc) (If ON) | 9.6 | 19.2 |
| Min Source Current (Ignition/Kill Inputs) | 10 micro-Amps | |
| Max 5 Min Current (Amps) 240 | | 10 |

Operating Current (mA) Standby / Open ACR #1/#2 Close Delay 120 s (Long), 30 s (Short) ACR #1/#2 Close Voltage (Vdc) 12.8 - 13.35 | 25.6 - 26.7 ACR #1/#2 Open Delay 30 s (Long), 10 s (Short)

ACR #1/#2 Open Voltage (Vdc) **Hardware Material**

12.2 - 12.75 24.4 - 25.5 Stainless Steel Self-Locking

Terminal Stud Torque Aux Output Max Drive Current

80 in-lbs 400 m-Amps

Maximum Cable Size Cable Size to Meet Ratings

2/0 AWG 6 AWG/2 AWG

Resell Pack **Bulk Pack** Part Numbers 7612 12V 2x80A Triple Battery ACR 7612B 24V 2x80A Triple Battery ACR 7612-24 7612-24B Kill Switch Kit for (-) Control 4600-1001 4600-1001B

* Custom product configurations available including stud sizes, control harness wires, time delays, voltage settings, dip switch functionality, and control input functionality. Low minimum quantities and short lead time for samples or production. Contact us at support@egismobile.com for more information







