## What's in the box?


#### Content

\_

Α	Head unit
В	Connector block
С	Advanced thermostat with fan and lights
D	Head unit cable / Ethernet cable
Е	Thermostat cable
F	Accessories (Stand, flush fitting)



### **System Overview**



# **Fridge Optimizer**

**Installation Manual** 

#### DC only






#### STAINLESS LOBSTER

7001 Seaview Ave NW Suite 160 #59 98117 Seattle, WA USA www.stainlesslobster.com

### **Installation Overview**



1. Turn off the refrigerator/freezer and unpack the Fridge Optimizer box.



2. Attach the advanced thermostat inside the fridge and pull the cable into the compressor room.



- 3. Move existing
  - cables to connector block (except those for the old thermostat). Attach block to compressor controller.



4. Connect the head unit and power on the fridge.

# Details

- 1. Disconnect or turn off power to refrigerator/freezer.
- Attach the advanced thermostat inside refrigerator/freezer (2a or 2b). Close to, and where air from the fan can flow over the evaporator (i.e. cold plate).

Route the white advanced thermostat cable from inside the fridge/freezer to the compressor location (via an existing drain pipe or other hole in the fridge/freezer)

 Disconnect and discard the old thermostat connectors marked 'C' and 'T' (fig. 3a).

> Connect the new advanced thermostat cable to the side of the connector block.

Move the existing -,+,+,F cables from compressor controller to the connector block (fig. 3b).

Attach the connector block to the compressor controller.

 Place the head unit in a desired location and connect the included black Ethernet cable. Turn on the fridge/freezer!

> Go to <u>www.stainlesslobster.com</u> for tips on how to use the visual data to optimize your system!


## Illustrations




2a. Optimal position for advanced thermostat in an open "shoe box" evaporator systems (no lid)



2b. Zip tie the advanced thermostat vertically to the underside of a net shelf in flat evaporator systems



3a. Remove old thermostat connectors



*3b. Move existing blade connectors to connection block*